sbc
SAIA BURGESS CONTROLS

3-phase bidirectional energy meter
for current converter metering with S0-output

Bidirectional energy meter with S0-interface. The S0 interface is a hardware interface for the transmission of measured values via pulses.

Specifications:

- 3-phase energy meter, $3 \times 230 / 400$ VAC 50 Hz
- Converter metering to 1500 A in both directions of current
- Display of the active power, voltage and current per phase
- Display of the total active power
- S0-output; independent of the direction of current
- 7-digit display for energy supply and feeding back
- Can be sealed and is provided with a sealing cap as an accessory
- Accuracy class B in accordance with EN50470-3,
  Accuracy class 1 in accordance with IEC62053-21

Order number

Standard version:	AWD3B5W10MC2A00
MID version:	AWD3B5W10MC3A00
Sealing caps:	4 104 7485 0

Technical data

Accuracy class	B in accordance with EN50470-3, 1 in accordance with IEC62053-21
Operating voltage	$3 \times 230 / 400$ VAC, 50 Hz
	Tolerance -20 %/+15%
Power consumption	Active 0.4 W per phase
Meter range	000˙000.0…9˙999˙999
Display	Backlit LCD, numbers 6 mm high
Display without mains electricity	Condenser protected LCD
	maximum 2 times in 10 days
S0-output (interface)	Optocoupler max. 30 V / 20 mA and min. 5 V, impedance 100 Ω, pulse duration 30 ms
Transmission distance	S0-output max. 1000m (at 30V/20mA)

Assembly

|	
Assembly	On 35 mm top-hat rail in accordance with EN60715TH35
Connections Main current circuit	Conductor cross section 1.5 – 16 mm², Pozidrive screwdriver size 1, flat-head screwdriver size 2, torque 1.5 – 2 Nm
Connections Control current circuit	Conductor cross section 2.5 mm², Pozidrive screwdriver size 0 or flat-head screwdriver size 2, torque 0.8 Nm
Insulating properties	4 kV / 50 Hz test in accordance with VDE0435 for energy meters
	6 kV 1.2 / 50 μs overvoltage in accordance with IEC255-4
	Device protection class II
Ambient temperature	–25 °…+55 °C
Storage temperature	–30 °…+85 °C
Environment	Mechanical M2 Electromagnetic E2
Relative humidity	75 % without condensation
EMC/resistance	Surge voltage in accordance with IEC61000-4-5 at the main current circuit 4 kV at the S0-interface 1 kV
	Burst voltage in accordance with IEC61000-4-4, at the main current circuit 4 kV at the S0-interface 1 kV
	ESD in accordance with IEC61000-4-2, contact 8 kV, air 15 kV

Converter measurement

	5…1500 A			
Reference current / maximum current	$I_{ref} = 5$ A, $I_{max} = 6$ A			
Start current / minimum current	$I_{st} = 10$ mA, $I_{min} = 0.05$ A			
Conversion factor	5:5	50:5	100:5	150:5
	200:5	250:5	300:5	400:5
	500:5	600:5	750:5	1000:5
	1250:5	1500:5		

Pulses per kWh	LED	10 pulses / kWh
	S0-output	10 pulses / kWh

Error display

Example: Connection error at L3

T→   T←   CT   Select   P (kW)
L1
L2
03.8
kWh
L3
Error   U (V)   I (A)

Example: Connection error at L1 and L3

T→   T←   CT   Select   P (kW)
L1
L2
03.8
kWh
L3
Error   U (V)   I (A)

Dimension drawings

70
57.7
22.7
30.5   9   9   4.5
68
69.5
kWh
35   11
7
5 x 11.7 = [58.5]   6

62
31
27
82   45
4.5
6

Display components

T→   T←   CT   Select   P (kW)
L1
L2
KWh
L3
Error   U (V)   I (A)

- T→   Shows the total consumption →
- T←   Shows the total consumption ←
- CT   Shows the set current converter ratio
- Select   When the Z1-Z2 bridge is open, the converter ratio can be set under the menu item: Select
- P (kW)   Shows the present output per phase or for all phases-
            Current «→» = supply (P positive)
            Current «←» = feeding back (P negative)
- U (V)   Shows the voltage per phase
- I (A)   Shows the current per phase
- kWh   Shows the unit kWh in the consumption display
- L1/L2/L3 Displays the corresponding phase for the P, U, I or error display
- Error   In the absence of a phase. The corresponding phase is also displayed.

Menu used to display the values on the LCD display

	Direction of current "supply ⟶"	Direction of current "feedback ⟵"
Output P	positive	negative
T⟶ is displayed if there is no flow of current.		

Current converter ratio (CT)

AWD3B5W10MC_A00   5 … 1500 A

5:5	50:5	100:5	150:5	200:5
250:5	300:5	400:5	500:5	600:5
750:5	1000:5	1250:5	1500:5	

Present output (P)

Voltage (U)

Current (I)

Connection diagram / Method of operation

Energy is added as indicated by the arithmetic operator. Positive output in the meter indicates that energy is being supplied, while negative output indicates that energy is being delivered. The energy measurement is carried out in accordance with mode 2, is balanced.

If the supply of energy (P positive) is greater than the delivery of energy (P negative), the counter T ⟶ increases.
The LED is OFF and only switches on if there is a pulse.

If the delivery of energy is greater than the supply of energy, the counter T ⟵ increases.
In this case the LED is ON and only switches off if there is a pulse.

The S0 output can be configured.

S0 IN: S0 pulses only for consumption

S0 OUT: S0 pulses only for feeding back

S0 BI: S0 pulses for both directions of current

Method of operation with direction of current «supply ⟶»

The secondary connection for the current converter on the network side is connected to the measuring phase. The current converter may not be earthed for this reason.

Fuse: T 250 mA (3×)

Mode of operation of the LED

S0 output: S0 BI parameterized

LED

t2 = x

x = depending of the energy consumption

t1=30ms
puls rate: 10/kWh

S0-output

HIGH

t2 = x

x = depending of the energy consumption

LOW

t1=30ms
puls rate: 10/kWh

Method of operation with direction of current «supply →» and «feeding back ←»

Feeding back   Energy supply

L1 →

L2 →

L3 ←

- - - - - - - - - - - - -

L1 →   L2 →

L3 ←

P+ →

Tariff "→" increases

5 ... 30 VDC

←→ = direction of current

Photovoltaic panel

Converter

⚠ The secondary connection for the current converter on the network side is connected to the measuring phase. The current converter may not be earthed for this reason.

3 × 230/400 VAC

L1
L2
L3
N
(PEN)   Fuse: T 250 mA (3×)

Mode of operation of the LED

LED

t2 = x

x = depending of the energy consumption

time

t1=30 ms
puls rate: 10/kWh

S0 output: S0 BI parameterized

S0-output

t2 = x

x = depending of the energy consumption

HIGH

LOW

time

t1=30 ms
puls rate: 10/kWh

Method of operation with direction of current «feeding back ←»

Feeding back   Energy supply

L1 →

L2 ←

L3 ←

- - - - - - - - - - - - -

L1 →

L3 ←   L2 ←

P- ←

Tariff "←" increases

5 ... 30 VDC

←→ = direction of current

Photovoltaic panel

Converter

⚠ The secondary connection for the current converter on the network side is connected to the measuring phase. The current converter may not be earthed for this reason.

3 × 230/400 VAC

L1
L2
L3
N
(PEN)   Fuse: T 250 mA (3×)

Mode of operation of the LED

LED

t2 = x

x = depending of the energy consumption

time

t1=30ms
puls rate: 10/kWh

S0 output: S0 BI parameterized

S0-output

t2 = x

x = depending of the energy consumption

HIGH

LOW

time

t1=30ms
puls rate: 10/kWh